

Customer information

2nd of February 2024, Version 1, FRI

Software update QUANTOFIX® Relax


Overview	
Reflectometer	QUANTOFIX® Relax
Version number	3.07
Availability	from 25 th August 2025
Price	free of charge
Available on	https://www.mn-net.com/de/relax-device-updates
Required accessories	USB stick



Important note

We recommend that you save your measurement data by printing or using the data export software before each update. For more information on data backup, please refer to the instrument manual.

Update procedure

- Download the update file via the link above and unzip the ZIP file on your PC.
- Copy the file "relax.bin" to the upper level of your USB stick and connect it to the device.
- Start the device and tap the screen repeatedly **during the start up** until a number entry field appears (*service menu*)
- Enter the code 1234
- Select *Program update* and wait until the update has finished (this process can take several few minutes)
- The device will now restart automatically. Wait until the device has restarted and performed the necessary self-tests. Do not switch off the device during this process.
- Restart the device again and open the *service menu* by repeatedly tapping on the screen
- Enter the code 1234
- Select Load default to reset the device
ATTENTION: After a Load default, all measurement data is deleted and the device is reset to the default settings
- Leave the *service menu* by pressing the -Button
- Check whether the update was successful via the version number displayed on the printout after a restart

Modifications

- Implementation of the QUNATOFIX® Relax Nitrite 25 test strip
- Optimization of parameters pH and sulfite
- Bug fixes

Contact

If you have further questions, please do not hesitate to contact us:

Technical support and customer service	Tel.:	+49 24 21 969-333
	E-Mail:	support@mn-net.com
For orders (international)	E-Mail:	sales@mn-net.com

